


TENMARS

Air Velocity Meter TM-411/412/413/414



User's Manual



HB2TM4110000

Contact :

EASTERN ENERGY CO.,LTD. (HEAD OFFICE)

40/4 Vitoondumri Rd., Banbueang, Banbueang, Chonburi 20170

Tel: 0-3844-6117 Fax: 0-3844-6200

Email: info@ete.co.th

www.ete.co.th


Table of Contents

1.	Introduction	1
2.	Features.....	1
3.	Functions Cross table	2
4.	Air Velocity Meter Features	3
5.	Display Features	5
6.	Power On/Off	6
7.	Auto Shutoff	6
8.	LED Backlight	6
9.	Auto Backlight On/Off	7
10.	Air Velocity Measures	8
11.	Change Secondary Display Mode.....	9
12.	Change Units	9
13.	Air Flow Calculation	10
14.	Setting Area	10
15.	MAX/MIN/AVG record:	11
16.	Freeze Display (HOLD).....	12
17.	99 Records	12
18.	Clear Memory	13
19.	Memory Recall	14
20.	Checking the LCD and Software Version	14
21.	Battery Replacement	15
22.	Specifications	15
23.	End of life	17

1. Introduction

TM-40X series measures air speed, temperature and humidity. It is ideal for spot measurements at air outlets on account of its 30mm vane. In addition to air speed and temperature, TM-404 also measures air moisture and absolute pressure. In this way, air conditions can be reliably checked.

2. Features

- 45mm 4 plastics vane
- High sensitivity of 0.4m/s.
- Air flow calculate function.
- Max/Min/Avg and data hold.
- Auto power off with disable function.
- Low battery indication. “”
- Low battery indication.
- Datalogging capacity: 99 records.
- Memory recall function.
- Backlight function.
- Absolute Pressure Sensor
- Humidity Sensor

3. Functions Cross table

	Velocity	Flow	99 Record	Temperature	Humidity	Pressure
TM-411 (with Vane-01)	●	●	●			
TM-412 (with Vane-02)	●	●	●	●		
TM-413 (with Vane-03)	●	●	●	●	●	
TM-414 (with Vane-03)	●	●	●	●	●	●

4. Air Velocity Meter Features



1. HOLD and Recall key
2. ESC and Rec key
3. Max, Min and AVG key
4. Select up and Auto shutoff key
5. Enter and Unit change key
6. Select down and Power key
7. backlight and Set Key
8. Display and Backlight
9. Probes input
10. Battery placement
11. Battery cover
12. Probes Plug
13. Probes hold
14. Probes sensor (Temperature/Humidity)
15. Vane
16. Internal Pressure Sensor (TM-414)

Contact :**EASTERN ENERGY CO.,LTD. (HEAD OFFICE)**

40/4 Vitoondumri Rd., Banbueng, Banbueng, Chonburi 20170

Tel: 0-3844-6117 Fax: 0-3844-6200

Email: info@ete.co.th


www.ete.co.th

5. Display Features



1. Primary display
2. Secondary display
3. Functional symbol display area
4. Lower battery indication.
5. Auto shutoff symbol indication.
6. Units of Primary display
7. Units of Secondary display

6. Power On/Off


In the shutoff mode Press  key to turn on the power.

If want to turn off Press and hold  key.

※ In the Set ,Unit change and recall mode can not turn off the power.


7. Auto Shutoff

The device will auto shutoff if there is no action for 15 minutes.

If want to disable or enable the auto power off function, please press and hold  key.

※In the Set ,Unit change and recall mode can not change this.

8. LED Backlight


When press  key to turn on backlight. Press key to turn off again. The backlight will turn off of after 30 seconds.

9. Auto Backlight On/Off


Users can set on or off the 30-seconds auto-off backlight

Press and hold  key into setting mode.

Press  and  key to select BLIGHT

setting, as shown in figures. Press  key into

Backlight setting. Press  and  key to


select auto off on or off. Press  key to finish

and leave setting mode.



10. Air Velocity Measures

1. Please insert probe plug into the device sensor input socket.
2. Follow the arrows to measure velocity. As shown in figures.



Contact :

EASTERN ENERGY CO.,LTD. (HEAD OFFICE)

40/4 Vitoondumri Rd., Banbueng, Banbueng, Chonburi 20170

Tel: 0-3844-6117 Fax: 0-3844-6200

Email: info@ete.co.th



www.ete.co.th




11. Change Secondary Display Mode

In the normal mode, Press  and  key to change secondary display mode.

※ In the Humidity mode need to waiting minutes to acquire accuracy humidity reading.

12. Change Units

Press and hold  key into the setting units mode. If want to change the secondary display units, please press and hold  key again.




When in the setting units mode, LCD blink the choose unit. Press  and  key to change the units and press  key to finish and leave setting mode.





13. Air Flow Calculation


When secondary display in the flow mode (CMM/CFM), the device will calculate flow by the users key in area volume.

14. Setting Area

Press and hold  key into the setting mode.

Press  and  key to select setting area mode, as shown in figures. Press  key into the setting area mode.




From left to right to set the digits, and press  and  key to adjust digits to left or right. Press  and  key to increase and decrease volume through last right digits.

Users can press and hold  key to change area units (m^2 / ft^2).





- ※ The units(m^2) maximum volume is $1.5 m^2$, and minimum volume is $0.096 m^2$.
- ※ The units (ft^2) maximum volume is $16.15 ft^2$, and minimum volume is $1.03 ft^2$.

15. MAX/MIN/AVG record:

This function can record maximum, minimum and average. User can select viewing. Press  key to start record MAX, MIN, and AVG. Show the max reading to display. Press  key to switch viewing between MAX, AVG and MIN. Press and hold  key to disable this function.

- ※ In the Set ,Unit change and recall mode can not used this function.


16. Freeze Display (HOLD)

Users can press  key to freeze display, and press  key again to release display.

※ In the Set ,Unit change and recall mode can not used this function.

17. 99 Records

Device cans storage air velocity data up to 99 records.

Press  key to storage once record data, and shown memory location on the LCD about 1 second.

※ When the enable HOLD and MAX/MIN function, the record data still real reading.

Contact :

EASTERN ENERGY CO.,LTD. (HEAD OFFICE)

40/4 Vitoondumri Rd., Banbueng, Banbueng, Chonburi 20170


Tel: 0-3844-6117 Fax: 0-3844-6200


Email: info@ete.co.th


www.ete.co.th



18. Clear Memory

When the memory are full or want to clear memory data, please follow the setup to clear memory.

Press and hold  key into the setting mode, as shown in figures.

Press  and  key to select the clear memory mode.


Press  key into the clear memory mode. The LCD showed the “yes” to reconfirm.

Press  key to leave or press  key to clear memory and leave clear memory mode.






19. Memory Recall

Users can recall the memory data to show on the display.


Press and hold  key into the RECALL mode.

The secondary display showed the memory location and primary display showed the storage velocity data.

Press  and  key to increase and decrease memory location.

If want to leave the recall mode, please press and hold  key to leave this mode.

20. Checking the LCD and Software Version


In the shutoff mode, Press and hold  key to turn on device and LCD will keep all dark continued.

Starting device will show the software version about 1 second.

21. Battery Replacement



WARNING

If the symbol “” appears on the LCD, please replace the battery immediately

Turn off the device and disconnect all test leads before replacing the battery.

Use only the correct type of batteries, properly installed in the case, to power the device.

22. Specifications

Velocity:

Unit	Range	Resolution	Accuracy
m/s	0.4~45	0.1	±3% +0.2
Km/hr(kph)	1.5~160	0.1	±3% +0.8
mph	0.9~100	0.1	±3% +0.4
Knots(kts)	0.8~88	0.1	±3% +0.4
ft/min(fpm)	79~8800	1	±3% +40
Beaufort	1~12	1	-

Air Flow Calculation:

Unit	Range	Resolution	Accuracy
CMM	0~9999	1	--
CFM	0~9999	1	--

Temperature:

Unit	Range	Resolution	Accuracy
°C	-20~60	0.1	±1°C
°F	-4~140	0.1	±1.8°F

Humidity:

Unit	Range	Resolution	Accuracy
%RH	20~80	0.1	±3.5%RH
%RH	<20 , >80	0.1	±5%RH


Absolute Pressure:

Unit	Range	Resolution	Accuracy
hPa	350~1100	0.1	±2hPa
mmHg	263~825	0.1	±1.5mmHg
inHg	10.3~32	0.1	±0.1

- Display : 42mm(W)*33mm(L) Monochrome LCD with backlight
- Battery : 9V (NEDA 1604 、 IEC 6F22 or JIS 006P)
- Battery Life : Approx continuous used 100 hours.
- Shutoff Rate Power : 3uA
- Operate Maximum Power : 25mA
- Operating temperature and humidity : 5°C to 40°C , below 80% RH.
- Storage temperature and humidity : -10°C to 60°C , below 70%.

- Instrument dimensions : 130(L)*56(W)*38(H) mm.
- Weight : About 160g.
- Probe dimensions : 135(L)*67(W)*31(H) mm.
Cable length: 95cm. Weight : About 100g.
- Accessories : User's manual x1, 9V battery x1, Probe x1, Bag x1

23. End of life

	<p style="text-align: center;">Caution</p> <p>This symbol indicates that equipment and its accessories shall be subject to a separate collection and correct disposal</p>
---	--

Contact :

EASTERN ENERGY CO.,LTD. (HEAD OFFICE)

40/4 Vitoondumri Rd., Banbueng, Banbueng, Chonburi 20170

Tel: 0-3844-6117 Fax: 0-3844-6200

Email: info@ete.co.th

www.ete.co.th

TENMARS



Professional Electrical and Environment Test & Measurement Instruments:

LED light meter, Temperature & Humidity meter,
Infrared Thermometer, Sound level meter
Light meter, EMF meter, UV Light meter,
RF meter, Hot wire Anemometer, Co meter
Anemometer, Lan cable tester, Co2 meter,
Solar power meter, Radiation meter,
Clamp meter, Multimeter, Phase Rotation test,
Digital Insulation tester

**Our products of high quality are selling
well all over the world**

Contact :

EASTERN ENERGY CO.,LTD. (HEAD OFFICE)

40/4 Vitoondumri Rd., Banbueng, Banbueng, Chonburi 20170

Tel: 0-3844-6117 Fax: 0-3844-6200

Email: info@ete.co.th

www.ete.co.th